

G3 BOOT SYSTEM PIPE INSTALLATION INSTRUCTIONS



- 1) Insert pipe into rolled in connector.
For inside mount, affix clamp behind O-ring. Torque to 60 in. / lbs. and backfill.



- 2) For outside mount: pull pipe back, repositioning pipe with-in wall and affix clamp behind O-ring. Torque to 60 in. / lbs. and backfill.

CAUTION: When installing pipe stubs for future pipeline, installation of all stubs should be properly restrained to prevent any movement.



697 Main Street • P.O. Box 1647 • Tullytown, PA 19007
800-822-2565 • 215-547-3366 • 215-547-5260 Fax