

Lift Insert Holders—for placement of all size Key-LOK Lift Inserts  
To specifically accommodate Key-LOK Lifting Pins

**LH-1099-U-P**



**LH-1099-U** (kit)

Urethane Lift Insert Holder



Universal Lift Insert Holder  
for  
All Size A-LOK Lift Inserts

**LH-109X-UNIV**

- Universal Holder works with all size wet and dry cast inserts
- Installed with KEY-LOK Washer shown below



**LH-KWASHER**

KEY-LOK Washer

**LH-109X-T-PR**

(Pull Ring)



**LH-109XC**

(Steel Collar)

**LH-1096-T-S**

or

**LH-1095-T-S**

(Tube Holder Shaft)



Coil Style Lift Insert Holder  
for 1095 A-LOK Lift Inserts

**Coil Style**



Coil Style Lift Insert Holder  
For 1098 A-LOK Lift Inserts

**LH-1095-C, LH-1096-C, LH-1097-C, LH-1098-C**

Coil Style Lift Insert Holders

- Works with both Wet and Dry Cast inserts all sizes
- Installed with KEY-LOK Washers shown above

**LH-109X-BR-P**

(Holding Pin)

Steel Collar

**LH-109X-BR-C** (centered)

or


**LH-109X-BR-C-O** (offset)



**LI-1095-BR**



CAM-LOK Lift Insert



Lift Insert Holder

**LH-109X-BR-I** (center)

or

**LH-109X-BR-I-O** (offset)

**LH-1095-T (centered) or LH-1095-T-O (offset)** (kit)

CAM-LOK Lift Insert Holder and Steel Collar to weld to jacket with centered or offset holding pin with tether

